



691 Brake Lock Installation Kits

You no longer need to spend time figuring out where to locate MICO 691 Brake Lock System components or how to mount them. The new MICO 691 Installation Kits contain the necessary components to install a 691 Brake Lock System on General Motors or FORD medium duty trucks. Save on installation time by using pre-formed mounting brackets and brake tubes that are custom fit for your application.

Kits Include:

- ✓ *Mounting brackets*
- ✓ *Pre-formed brake tubes and hoses*
- ✓ *Nuts, bolts, and mounting hardware*
- ✓ *Brake line fittings*
- ✓ *Detailed installation instructions*

Benefits:

- ✓ *Reduced installation time*
- ✓ *Use existing frame rail holes*
- ✓ *No tube bending or flaring*
- ✓ *No forming brackets or shields*
- ✓ *All installations are consistent*



MICO, Incorporated

1911 Lee Boulevard (Zip Code 56003-2507)
P.O. Box 8118 / North Mankato, MN U.S.A. 56002-8118
☎ 507.625.6426 Facsimile 507.625.3212

Web site: www.mico.com

Form No. 80-690-041

Revised 4/28/05



GM C4500/C5500 model years 2003-2005

691 Installation Kits:

For Front Wheel Lock-up order 02-603-006
For Rear Wheel Lock-up order 02-603-007
For 4-Wheel Lock-up order 02-603-002

691 Brake Lock Systems:

For Front or Rear Wheel Lock-up order 02-691-209
For 4-Wheel Lock-up order 02-691-403

FORD F450/F550 model years 1999-2004

691 Installation Kits:

For 4-Wheel Lock-up order 02-603-001
7.3 liter Powerstroke diesel (1999-2003)
V8 & V10 gasoline (1999-2002)

691 Brake Lock Systems:

For 4-Wheel Lock-up order 02-691-305

FORD F450/F550 with 6.0 liter Powerstroke diesel engine model years 2003-2004

691 Installation Kit:

For 4-Wheel Lock-up order 02-603-008
(not for use with gasoline engines)

691 Brake Lock System:

For 4-Wheel Lock-up order 02-691-305

