



Manufactured by – Petersen Brands – 3721 N. Ventura Drive, Suite 180 – Arlington Heights, IL 60004

Thank you for purchasing the Wobble Light®. Your Wobble Light® should endure normal abuse and last trouble free for years. In the rare case that you do have a problem, or can not find replacement bulbs in your area, please feel free to call our customer service at 877-707-0800 or contact us through our web site at www.wobblelight.com.

WARNING! DO NOT plug power into the Wobble Light® until it is completely assembled.

WARNING! Bulbs get very hot immediately upon illumination and can cause burns.

WARNING! Bulbs stay hot for an extended period of time after the Wobble Light® has been turned off and can cause burns.

CAUTION! If your light cycles on and off, it may indicate that the light is overheating. Stop using the light immediately and contact the manufacturer.

Operate in an upright position only. Do not hang the light upside down.


Assembly Instructions:

1. Holding the bulb by the base, gently screw the light bulb assembly into the socket. Be careful not to put too much pressure on the bulb or it will break. If you feel resistance in the socket it may be necessary to use electrical grease, otherwise, back the bulb out slightly and then rethread it into the socket. Be careful not to cross thread the bulb. Tighten bulb until it is completely seated in the socket. Do not over tighten.
2. Attach the polycarbonate dome to the top of the Wobble Light® using the five screws provided. Make sure that the handle points towards the same side as the power switch.
3. Plug a three pronged extension cord into the Wobble Light® and test to see that it works properly. Please note that **metal halide units must warm up for approximately 5-8 minutes before full brightness is achieved.** Conversely, metal halide units must rest after use for approximately 7-8 minutes before they will restart.

Assembly Instructions (Fluorescent Model Only):

1. Grip bulb by plastic base and screw into Wobble Light® socket.
2. Attach clear plastic dome to the Wobble Light® using the five screws provided. The handle on the dome should be on the same side as the power switch.
3. Plug Wobble Light® into a three pronged extension cord and flip switch to on position. The light will come on immediately but will not achieve full brightness for 5-8 minutes

DO NOT REMOVE SILICONE BUMPERS FROM BULB!



WL120F



Manufactured by – Petersen Brands – 3721 N. Ventura Drive, Suite 180 – Arlington Heights, IL 60004

Trouble Shooting:

I have assembled my Wobble Light®, but it does not work.

Check to see that the on off switch is in the correct position and that the extension cord is plugged into an outlet that has power.

Check to make sure that the bulb is screwed completely.

WL175MH, WL250MH, WL400MH (Metal Halide Units)

Metal halide bulbs need about 15-30 seconds to start, and then another 5-8 minutes to warm up to full brightness. You may have inadvertently switched the light off before it had enough time to start. If that did happen, you will have to wait 7-8 minutes for the catalyst inside the bulb to reform before it will start again.

Check to make sure that the bulb is screwed completely into the light socket.

For any other problems, contact us at 877-707-0800 M-F between the hours of 8:30a and 5:00p CST

Limited Product Warranty

Coverage and Duration: Wobble Light® products, excluding bulbs, are warranted against defects in material and workmanship for a period of 1 Year from date of purchase (restrictions may apply outside the U.S.). This warranty does not cover:

- damages or repairs of any kind to any products, items or personal or other property resulting from use of your Wobble Light® product
- any damages caused by accidents, or abuse or misapplication of the Wobble Light® product
- failure of the Wobble Light® product to meet your requirements that differ from our specifications
- any damages caused by use of the Wobble Light® product that is contrary to the instructions or documentation accompanying your Wobble Light® product
- costs of shipment or delivery for any returns or repairs under this Limited Warranty
- damages from fire, flood, moisture, heat, acts of God or causes beyond our control
- the repair or replacement of a Wobble Light® that has been transferred to anyone other than the original purchaser

Wobble Light, LLC 3721 N. Ventura Drive, Suite 180 Arlington Heights, IL 60004		Registration Card service@wobblelight.com	
Product(s) Purchased		Purchase Date	
Business Name			
Street Address			
City	State	Zip	
Email Address			
Business Phone Number (Include Area Code)			
Customer/Contact Person & Title			
Product Purchased From			